

Item	Sub	Parts No.	Parts Description	Qty
1		911274-7	PAN HEAD SCREW M5X50	2
2		AL00000002	WHEEL COVER L	1
3		AL00000003	HEX NUT M12L	1
4		AL00000004	OUTER FLANGE	1
5		AL00000005	INNER FLANGE	1
6		911206-4	PAN HEAD SCREW M5X10	3
7		AL00000006	WHEEL COVER L	1
8		911107-6	PAN HEAD SCREW M4X8	4
9		AL00000007	CORD CLAMP	1
10		942101-7	SPRING WASHER 5	1
11		931201-8	HEX. NUT M5	1
12		AL00000008	LAMP COVER BASE	1
13		AL00000009	NUT	1
14		911107-6	PAN HEAD SCREW M4X8	2
15		AL00000010	STRAIN RELIEF	1
16		911118-1	PAN HEAD SCREW M4X12	2
17		911156-3	PAN HEAD SCREW M4X30	2
18		AL00000011	LAMP COVER	1
19		AL00000012	LAMP HOLDER ASSY	1
20		AL00000013	BULB	1
21		AL00000014	ADJUSTABLE KNOB	1
22		921351-7	HEX. BOLT M6X30	1
23		941151-9	FLAT WASHER 6	1
24		AL00000015	EYESHIELD MOUNTING ARM L	1
25		AL00000016	SAFETY EYE SHIELD	1
26		931201-8	HEX. NUT M5	1
27		942101-7	SPRING WASHER 5	1
28		921212-1	HEX. BOLT M5X12	1
29		942101-7	SPRING WASHER 5	1
30		AL00000017	SPARK DEFLECTOR (LEFT)	1
31		AL00000018	WORK REST (LEFT)	1
32		941202-8	FLAT WASHER 8	2
33		942101-7	SPRING WASHER 5	1
34		931201-8	HEX. NUT M5	1
35		921411-5	HEX. BOLT M8X12	2
36		265004-1	PAN HEAD SCREW M5X135	4
036-1		AL00000113	SCREW M5X135	4
37		941101-4	FLAT WASHER 5	4
38		AL00000019	MOTOR HOUSING COVER R	1
39		211206-7	BALL BEARING 6202LLB	1
40		951051-5	SPRING PIN 3-8	2
41		AL00000215	ROTOR	1
041-1		AL00000229	ROTOR	1
42		AL00000185	STATOR	1
042-1		AL00000228	STATOR	1
43		AL00000022	BUSH	1
44		AL00000023	MOTOR HOUSING	1
45		911113-1	PAN HEAD SCREW M4X10 WITH WR	4
46		AL00000024	CORD CLIP PLATE	1
47		911113-1	PAN HEAD SCREW M4X10 WITH WR	2
48		AL00000173	POWER SUPPLY CORD	1
51		AL00000026	CORD GUARD	3
52		211206-7	BALL BEARING 6202LLB	1
53		AL00000027	WAVE WASHER	1
54		AL00000028	MOTOR HOUSING COVER L	1
55		942101-7	SPRING WASHER 5	1
56		931201-8	HEX. NUT M5	1
57		931402-8	HEX. NUT M8	1

Item	Sub	Parts No.	Parts Description	Qty
58		911113-1	PAN HEAD SCREW M4X10 WITH WR	1
59		AL00000029	CAPACITOR CLAMP	1
60		AL00000095	CAPACITOR	1
61		942051-6	SPRING WASHER 4	2
62		931102-0	HEX. NUT M4	4
63		942051-6	SPRING WASHER 4	2
64		911113-1	PAN HEAD SCREW M4X10 WITH WR	6
65		AL00000031	SWITCH BOARD	1
66		911113-1	PAN HEAD SCREW M4X10 WITH WR	2
67		AL00000032	SWITCH ASSY COVER	1
067-1		AL00000168	SWITCH WITH COVER	1
68		AL00000033	SWITCH COVER ASSY	1
69		AL00000134	TOOTHED LOCK WASHER 4	1
70		911113-1	PAN HEAD SCREW M4X10 WITH WR	1
72		AL00000034	WHEEL COVER R	1
73		AL00000035	HEX NUT M12	1
74		AL00000004	OUTER FLANGE	1
75		AL00000013	BULB	1
76		AL00000011	LAMP COVER	1
77		911156-3	PAN HEAD SCREW M4X30	2
78		911118-1	PAN HEAD SCREW M4X12	2
79		AL00000010	STRAIN RELIEF	1
80		911107-6	PAN HEAD SCREW M4X8	2
81		AL00000009	NUT	1
82		AL00000008	LAMP COVER BASE	1
83		AL00000012	LAMP HOLDER ASSY	1
84		AL00000007	CORD CLAMP	1
85		911107-6	PAN HEAD SCREW M4X8	4
86		AL00000036	SPARK DEFLECTOR (RIGHT)	1
87		942101-7	SPRING WASHER 5	1
88		921212-1	HEX. BOLT M5X12	1
89		AL00000037	SAFETY EYE SHIELD WITH MAG	1
90		AL00000038	EYESHIELD MOUNTING ARM R	1
91		AL00000014	ADJUSTABLE KNOB	1
92		AL00000039	COOLANT TRAY	1
93		AL00000040	COOLANT TRAY PLATE ASSY	1
94		AL00000041	RUBBER SLEEVE	4
95		941051-3	FLAT WASHER 4	4
96		911121-2	PAN HEAD SCREW M4X14	4
97		921351-7	HEX. BOLT M6X30	1
98		941151-9	FLAT WASHER 6	1
99		931201-8	HEX. NUT M5	1
100		942101-7	SPRING WASHER 5	1
101		931201-8	HEX. NUT M5	1
102		942101-7	SPRING WASHER 5	1
103		AL00000005	INNER FLANGE	1
104		911206-4	PAN HEAD SCREW M5X10	3
105		AL00000042	WHEEL COVER R	1
106		AL00000043	WORK REST (RIGHT)	1
107		942101-7	SPRING WASHER 5	1
108		931201-8	HEX. NUT M5	1
109		941202-8	FLAT WASHER 8	2
110		921411-5	HEX. BOLT M8X12	2
111		911267-4	PAN HEAD SCREW M5X45	4
A01		AL00000044	WRENCH 10-13	1
A02		AL00000045	WRENCH 8-19	1
A03		A-47204	GRINDING WHEEL(BENCH,150)	1
A03-1		B-51932	GRINDING WHEEL (BENCH,150)	1
A04		A-47210	GRINDING WHEEL (BENCH,150)	1

Item	Sub	Parts No.	Parts Description	Qty
A04-1		B-51926	GRINDING WHEEL (BENCH,150)	1
F01		AL00000147	SAFETY GOGGLES	1